Aleaferm MP



COMPOSITION

Active dry yeast *Metschnikowia pulcherrima* Contains E491 sorbitan monostearate.

GENERAL CHARACTERISTICS

Appearance: small beige-colored sticks with a characteristic odor.

ALEAFERM MP has special characteristics that make it suitable for bioprotection:

- Controlling natural flora during harvesting
- Reducing the amount of compounds that combine SO2
- Increasing the aromatic complexity of the wine
- Decrease the dosage of SO2 on the grapes

Total yeast	Vital yeast	Moulds	Lactic bacteria	Dry matter
> I0x10°UFC/g	> 10x10 ⁹ UFC/g	< 103 UFC/g	< 10 ⁵ UFC/g	> 93%

APPLICATIONS

ALEAFERM MP is suitable for colonizing an environment and preventing the growth of unwanted microorganisms. It provides Bioprotection and can be used before fermentation, on the must,

RECOMMENDED DOSAGES

3-5 g/hl

At the end of the pre-fermentation phase, inoculate the appropriate dose of *Saccharomyces cerevisiae* to start alcoholic fermentation.

MODE OF USE

Inoculate directly or rehydrate **ALEAFERM MP** in warm water (at a ratio of 1:10), temperature between 30° and 33°C, for better distribution.

The temperature difference between the must to be inoculated and the yeast suspension should be less than 10° C.

Add the yeast suspension to the wort when starting to fill the fermentation tank and homogenize thoroughly. The total rehydration preparation time should not exceed 4 hours. Use an inert and clean container.

PACKAGES AVAILABLE

500 g bag

STORAGE CONDITIONS

Unopened package: store in a cool (possibly refrigerated at 4°C), dry and ventilated place. Open package: close tightly and store as indicated above.

Exclusively for oenological and professional use - Reg. (EU) 2022/68 Product obtained from raw materials in accordance with O.I.V. International Oenological Codex

The information given in this Technical Data Sheet corresponds to the current state of our knowledge and is subject to modification and supplementation without prior notice. The methods of use given do not relieve the user from the application and observance of safety and protection regulations. Adaptation to individual cases, as a consequence of the specific circumstances of each use, as well as possible misuse of the product, do not involve the responsibility of Alea Evolution S.R.L.



Via Sandro Pertini, 12 40062 Molinella (BO) - ITALIA Tel. +39 051 88 7052 +39 346 58 33 882 info@alea-evolution.com alea-evolution@pec.it alea-evolution.com CF - P.IVA 02944251202 Cod. REA BO-479327 Capitale sociale € 40.000,00 i.v.